

Edge Computing Hands-On Lab


Using the pre-built solution for cookie defect identification

Step 1: (Optional) Install Python and the Development tools

1. Install Python, VS Code and tools.
Follow this tutorial: [Install and configure Visual Studio Code for Python development - Training | Microsoft Learn](#)
2. Ensure the following modules are installed.
 - a. requests

```
pip install requests
```
 - b. pygame


```
pip install pygame
```
3. Fork from this Git repository: <https://github.com/ThulaseeShan/PySimulator> to your own GitHub repository




4. Connect VS Code to your GitHub repository (we created this during the first lab session)
5. Sync up the code to your laptop / machine
If you don't know how to work with Git repository using VS Code, refer this: [Collaborate on GitHub \(visualstudio.com\)](#)

Step 2: Run the Simulator for the first time.


1. Once the code is synced select the main.py and click run in Python Debugger (otherwise you might see some error messages). No code changes would be required for the 1st run.



2. If everything is set up correctly, you should see the simulator running as follows




- Wait until you see 50 captured files created in the “captures” folder and then close the simulator. You may also watch the row numbers (on the bottom of the simulator screen) until they reach 55 - 60.




Step 3: Setting up a Custom Vision AI Project in Azure Portal

1. Login to the Azure portal in your browser and search for “custom vision” in the top search bar and select the option “Custom vision”



2. Click “Create” from the top tool bar



3. Fill out the information on the next screen. Ensure you have given your student id as the instance name and selected Free F0 as the pricing tier. You can have only 1 free resource. If you have already created it before, you will have to delete and recreate.

[Home](#) > [Azure AI services](#) | [Custom vision](#) >

Create Custom Vision ...

Basics Network Tags Review + create

Customize and embed state-of-the-art computer vision for specific domains. Build frictionless customer experiences, optimize manufacturing processes, accelerate digital marketing campaigns -- and more. No machine learning expertise is required.

[Learn more](#)

Create options *

- ☒ Both
☐ Prediction
☐ Training

Project Details

Subscription * ⓘ

MCAPS-Hybrid-ThulaseeShan

Resource group * ⓘ

AzMigrate

[Create new](#)

Instance Details

A training resource and a prediction resource will be created in same region.

Region ⓘ

East US

Name * ⓘ

STUDENT-ID-00123

Training Resource

Select pricing for training Resource.

Training pricing tier * ⓘ

Free F0 (2 Transactions per second, 2 Projects)

[View full pricing details](#)

Prediction Resource

Select pricing for prediction Resource.

Prediction pricing tier * ⓘ

Free F0 (2 Transactions per second)

[View full pricing details](#)

[Previous](#)

[Next](#)

[Review + create](#)

4. Once the instance is created click the 1st resource and then select “Custom Vision portal”. This will open in a new tab and then sign in to the portal (it should use the same login as Azure portal)

The screenshot shows the Azure portal interface for a Custom Vision resource named 'cookie-tester'. The left sidebar contains a navigation menu with categories like Overview, Activity log, Access control (IAM), Tags, Diagnose and solve problems, Resource Management, Keys and Endpoint, Encryption, Pricing tier, Networking, Identity, Cost analysis, Properties, Locks, Security, Microsoft Defender for Cloud, Monitoring, Alerts, Metrics, Diagnostic settings, Logs, Automation, Tasks (preview), Export template, and Help. The main content area is divided into 'Essentials' and 'Get Started' sections. The 'Essentials' section displays resource details: Resource group (move) : cookie-tester, Status : Active, Location : East US, Subscription (move) : MSDN, Subscription ID : 4f4d5e3c-367f-4b2f-b4f5-dafdd270ff04, and Tags (edit) : Add tags. The 'Get Started' section has a 'Monitoring' tab and a 'Custom Vision portal' link highlighted with a red box and a red arrow. The 'Custom Vision portal' link is part of a list of quickstarts: 1. Get the API Key to authenticate your applications and start sending calls to the service. All Custom Vision calls require a key. The key can be found in the Keys and Endpoint section in the left pane. Specify the key either in the request header (Web API) or in the Custom Vision client API Key. 2. Try the service in the Custom Vision portal - requires API Key. Use the Custom Vision portal to quickly try the API without writing code. You can use the Custom Vision SDKs to implement all of this functionality programmatically when you are ready to build. 3. Make a web API call - requires API Key and location. Use the sample code in these quickstarts to begin integrating the Custom Vision service into your applications to recognize the categories you care about in your images. The API key and the location are in the Keys and Endpoint section in the left pane. Below the quickstarts are links for C# Quickstart, Python Quickstart, NodeJS Quickstart, Java Quickstart, and Go Quickstart.

5. Once in the customvision.ai portal, click the new project link

The screenshot shows the Custom Vision portal interface. At the top, there is a message 'Looking for other directories?' with a 'Switch directory' button. Below this is the 'Projects' section. It includes a search bar for 'Project Name', a dropdown for 'Project Type' (set to 'Any project type'), and a dropdown for 'Resource' (set to 'All'). There is a 'NEW PROJECT' button with a folder icon and a plus sign. To the right of the 'NEW PROJECT' button is a project card for 'cookie-tester' with a thumbnail image of a cookie. A red arrow points from the 'NEW PROJECT' button to the 'cookie-tester' project card.

6. Provide your student id again as the name of the project and select “Object Detection” as the project type and “General (compact) [S1]” as the Domain. If this is not selected, you won’t be able to build the Docker Container.

Create new project

Name*

STUDENT-ID-00123

Description

Enter project description

Resource*

cookietest [F0]

[create new](#)

[Manage Resource Permissions](#)

Project Types ⓘ

☐ Classification

☒ Object Detection

Domains:

☐ General [A1]

☐ General

☐ Logo

☐ Products on Shelves

☒ General (compact) [S1]


☐ General (compact)

Pick the domain closest to your scenario. Compact domains are lightweight models that can be exported to iOS/Android and other platforms. [Learn More](#)


Cancel

Create project


- Once the project is created, select the “Add images” button and upload all the 50 images generated by the simulator.



- When the uploading is completed, select the image and tag each cookie appropriately. Select the good cookies and tag them as “Good” while the defect cookies as “Bad”. Pay attention to the letter-case, as python code may not work if you misspell them or change the letter-case




9. After tagging all the 50 images, click on the “Train” from the top, to train the AI model




10. Then select the “Quick Training”, and then click “Train” button. This would take 30 to 60 minutes to complete.



11. When the training is completed, you should see the precision above 85%. If not, the number of images you trained is not enough and you will have to bring more images and train the AI multiple times.



12. When you are satisfied with the results, click on “Publish” and select the Prediction resource you create earlier and publish



cookie-tester Training Images Performance Predictions Train Quick Test

Iterations

Probability Threshold: 50%
Overlap Threshold: 30%

Iteration 4
Trained : 7 hours ago with General (compact) [S1] domain

Iteration 3
Trained on: 9/25/2024 with General (compact) [S1] domain

Iteration 2
Trained on: 9/25/2024 with General [A1] domain

Iteration 1 PUBLISHED
Trained on: 9/25/2024 with General [A1] domain

✓ Publish Prediction URL Delete Export

Iteration 4

Finished training on 10/2/2024, 3:01:58 PM using General (compact) [S1] domain
Iteration id: d869ab9c-bcd2-44e0-9d79-ccc97cbe77e9

Publish Model

We only support publishing to a prediction resource in the same region as the training resource the project resides in.

Please check if you have a prediction resource and if the prediction resource is in the same region as the training resource.

Model name
Iteration4


Prediction resource
cookie-test-Prediction

Publish Cancel


Tag	Precision	Recall	A.P.	Image count
Good	90.0%	77.1%	85.5%	57
Bad	85.0%	81.0%	80.5%	42

100%
Get started


13. After publishing, you should be able to get the URL and Prediction-Key (aka API Key) from the Prediction URL option from the top menu.



14. Export the Docker Container to build your Edge node




15. Select appropriate OS, where you intend to run the docker and download the zip file




16. Unzip this to a folder and ensure you see the “Dockerfile” this the important file to build the docker container later.

Step 4: Testing the Cloud Analyzer with the Simulator


1. Go back to the python code and open the “cloud_module.py” file and replace the “[CLOUD URL]” and “[API KEY]” with the values from the publish settings



2. Save this file and open the main.py. Then set the shouldAnalyzeImg to True




3. Run the application in debug mode (refer to the point Step-2.1 above). Observe the RTT (round trip time) to get the results from the cloud.



Step 5: (Optional) Setup Docker in Linux environment

Do this, only if you don't have Docker installed already.

1. Install WSL and Ubuntu. This will install Windows Subsystem for Linux, which is easier to work on Linux without leaving Windows. Run the following command on your command window "wsl --install"



```
Administrator: Command Prompt - wsl --install
Microsoft Windows [Version 10.0.26100.1742]
(c) Microsoft Corporation. All rights reserved.

C:\Users\WDAGUtilityAccount>wsl --install
Downloading: Windows Subsystem for Linux 2.2.4
```

2. Install docker on Linux. Follow the instructions here: [How To Install and Use Docker on Ubuntu 20.04 | DigitalOcean](#)

Step 6: Running and Testing Edge Module with Simulator

1. Extract the zip file you downloaded and then navigate to the folder where you find the “Dockerfile” on Linux. Run the docker build command as follows

```
thulasee@DESKTOP-...:/mnt/c/Users/...$ cd Downloads/cookie-docker/
thulasee@DESKTOP-...:/mnt/c/Users/.../Downloads/cookie-docker$ sudo docker build -t cookie-detect .
```

2. Once the docker image is built, run the image using the following command


```
thulasee@DESKTOP-...:/mnt/c/Users/.../Downloads/cookie-docker$ sudo docker run -d -p 80:80 cookie-detect
```

3. If it is running successfully, you should see a log code without any error messages.
4. Now get the IP address of your WSL / Linux

```
thulasee@DESKTOP-...:/mnt/c/Users/...$ hostname -I
172.23.94.200 172.17.0.1
```


5. This is our edge IP address that we will be using with our Edge module

6. Go to the python code and open the “edge_module.py” and update “[EDGE URL]” with your IP address. E.g. if the IP address shows as 172.23.94.200, then the URL will be “http://172.23.94.200:80/image”. Update the same API key used in the cloud module above (Step-4.1)




```
5 -----
6 Change this file appropriately
7 1. update the endpoint URL
8 2. update the API Key or update your environment variable
9 3. (If required) change the logic
10 -----
11 ...
12
13
14 import time
15 import json
16 import requests
17 import os
18
19 class EdgeAnalyzer:
20     def __init__(self):
21         self.endPoint = 'http://172.23.94.200:80/image'
22         self.apiKey = '[API KEY]'
23
24     def analyzeImage(self, filePath) -> int:
25         start_time = time.time()
26         url = self.endPoint
27         headers = {
```

7. Now set the isCloud=True to False, in the “main.py” to run the edge module instead of the cloud module.



```
16 def main():
17
18     # Parameters:
19     # 1. isCloud
20     # =True : Uses cloud module
21     # =False: Uses edge module
22     analytic = analytic_module.Listener(isCloud=False)
23
24     # Parameters:
25     # 1. shouldAnalyzeImg
26     # =True : To analyze the images
27     # =False: To get images for training
28     # 2. imgLimit
29     # =Number: Number of images/rows to be stored (use 50 to get images for training)
30     conveyor = conveyor_module.Simulation(shouldAnalyzeImg=True, imglimit=50)
31
32     analytic.start()
33     conveyor.start()
34
35 if __name__ == "__main__":
36     main()
```

8. Run the application in debug mode (refer to the point Step-2.1 above). Observe the RTT (round trip time) to get the results from the edge.



Step 7: Assignment

1. Create a PPT file in your OneDrive (like assignment 1) and capture the following 7 screen into 7 different slides and share it with me. The title slide should have your name and student Id. All the text should be clear. If you miss anything, you will get 0 marks.
 - i. Customvision.ai portal screen showing the iterations and the precision
 - ii. The tagged images screen in the customvision.ai portal
 - iii. Output of the published prediction URL
 - iv. Output of the docker container in running state
 - v. `cloud_module.py` code update screen
 - vi. `edge_module.py` code update screen
 - vii. Screen shot of `edge_module` output in the terminal window along with the simulator running side-by-side